Agricultural Marketing Service Quality Assessment Division 1400 Independence Avenue SW, Stop 0249 Washington, DC 20250 QAD 603 Procedure August 31, 2018 Page 1 of 2

THERMOMETERS

Purpose

This instruction defines how to calibrate thermometers to be used by USDA graders.

Policy

Graders and Supervisors will ensure all thermometers are calibrated prior to production. Accuracy is critical when certifying temperature for contract acceptance and commodity specifications. Graders are to utilize thermometers provided by the production facility which have been calibrated.

Procedure

If thermometers are not available, the following procedure for calibrating thermometers will be utilized. For calibration of metal stem thermometers, certified thermometers have been provided to all Supervisors. The frequency and procedures for checking thermometer accuracy will be as follows:

- 1. Certified Test Thermometer These certifications are good for one year. When the certification period expires or the thermometer becomes damaged, the Supervisor is to order a new certified test thermometer. The old thermometer can no longer be used and since it does not contain mercury can be discarded in any trash receptacle.
- 2. Digital Thermometer The accuracy of each digital thermometer is to be verified by the Supervisor or assigned representative at least annually. This is to be accomplished by comparing the temperature readings of the digital thermometer, coupled with the immersion probe, with a certified test thermometer. A certified digital thermometer can be used to verify the accuracy of another digital thermometer.
 - To verify accuracy, collect a test medium from tap water. While agitating the water, read both thermometers for comparison. If there is more than a 1°F difference, the Supervisor is to request a new digital thermometer thru the Business Operations Branch in Little Rock, AR. If the temperature of the digital thermometer is within 1°F of the test thermometer, the digital thermometer is considered accurate.
- 3. Grader's Pocket Thermometer The accuracy of the grader's metal stem pocket thermometer (including any back-up thermometers) is to be verified by the Supervisor or assigned representative on a semi-annual basis. This is to be accomplished by collecting a test medium from tap water. With continuous agitation, place the digital thermometer and the pocket thermometer in the center of the water bath. After the temperature of both thermometers has stabilized, read and compare the temperatures to assure that they are within 2°F of each other.

If there is more than a 2°F difference, the pocket thermometer must be adjusted or replaced. In either case, the thermometer must be re-tested for accuracy.



Agricultural Marketing Service Quality Assessment Division 1400 Independence Avenue SW, Stop 0249 Washington, DC 20250 QAD 603 Procedure August 31, 2018 Page 2 of 3

During periods between the semi-annual verification when the grader suspects that the pocket thermometer is not accurate or they have been provided a new thermometer which has not been certified as accurate, they are to use the following method:

Prepare an ice water bath (mixture of ice and water). With continuous agitation, immerse the pocket thermometer in the center of the water bath. After the thermometer temperature has stabilized, the temperature reading should be between 31°F and 33°F. If the temperature is out of the accepted range, the thermometer cannot be used and must be adjusted or replaced.

During the next supervisory visit, graders are to request supervisors to formally re-test the pocket thermometer as outlined in item 3. If the temperatures are within 1° F of each other, the pocket thermometer is considered accurate.

Thermometers are also to be calibrated when:

- 1. Product is rejected based on thermometer readings and the thermometer had not been calibrated that day.
- 2. There is any reason to suspect readings may be in error.
- 3. Requested by applicant or financially interested party.

Note: Mishandling can impair a thermometer's accuracy. Handle thermometers with care and use only to take temperatures. Keep thermometers in their cases when not in use. Carefully clean thermometers before storing. Only expose thermometers to temperatures within range shown on dial.

Richard H. Lawson, National Poultry Supervisor

Quality Assessment Division Livestock and Poultry Program

But Il Lan

In accordance with Federal civil rights law and U.S. Department of Agriculture (USDA) civil rights regulations and policies, the USDA, its Agencies, offices, and employees, and institutions participating in or administering USDA programs are prohibited from discriminating based on race, color, national origin, religion, sex, disability, age, marital status, family/parental status, income derived from a public assistance program, political beliefs, or reprisal or retaliation for prior civil rights activity, in any program or activity conducted or funded by USDA (not all bases apply to all programs). Remedies and complaint filing deadlines vary by program or incident.

Persons with disabilities who require alternative means of communication for program information (e.g., Braille, large print, audiotape, American Sign Language, etc.) should contact the responsible Agency or USDA's TARGET Center at (202) 720-2600 (voice and TTY) or contact USDA through the Federal Relay Service at (800) 877-8339. Additionally, program information may be made available in languages other than English.

To file a program discrimination complaint, complete the USDA Program Discrimination Complaint Form, AD-3027, found online at How to File a Program Discrimination Complaint and at any USDA office or write a letter addressed to USDA and provide in the letter all of the information requested in the form. To request a copy of the complaint form, call (866) 632-9992. Submit your completed form or letter to USDA by: (1) mail: U.S. Department of Agriculture, Office of the Assistant Secretary for Civil Rights, 1400 Independence Avenue, SW, Washington, D.C. 20250-9410; (2) fax: (202) 690-7442; or (3) email: program.intake@usda.gov.